

CLEANING GUIDE

CONGRATULATIONS ON YOUR NEW FLOOR COATING!



USE & CARE INSTRUCTIONS

WWW.PENNTEKCOATINGS.COM

Area Home Services offers a solvent based industrial strength floor cleaner that has been designed specifically to work with **Penntek Coatings**. When mixed with warm water, the liquid concentrate will make your floors sparkling clean!



Area-HomeServices.com | 573.719.1412

WHEN THE INSTALL IS COMPLETE

- Do not close the garage door until the morning after install is complete.
- Please allow a minimum of 6-8 hours before walking on, depending upon humidity. Waiting until the next morning is ideal.
- You may drive on the floor 24 hours after install is complete, again depending on humidity. Waiting 36-48 hours is ideal. The floor will reach full chemical resistance at 72 hours of cure time.
- DO NOT use Rubber Mats. We recommend "Safe for Wood" Floor Mats

RESIDENTIAL - COMMERCIAL - INDUSTRIAL

You will be happy to know that your floor is easy to maintain!



ONGOING MAINTENANCE

Area Home Services offers a solvent based industrial strength floor cleaner that has been designed specifically to work with **Penntek Coatings**. When mixed with warm water, the liquid concentrate will make your floors sparkling clean! If you prefer, you may use your favorite floor cleaner to manufacturers specifications. We recommend **Simple Green, Pine Sol, CLR** and **Dawn**. Avoid long term exposure to bleach and stay away from acids and highly corrosive materials. Sweep off sand and salt then simply rinse with water. A squeegee works great to clear water off. For tougher cleaning let the cleaner sit on the floor for 5 - 10 minutes and scrub with a scrub brush or stiff bristle broom, wait an additional 5 minutes followed by a rinse for a revitalized floor.



Area-HomeServices.com | 573.719.1412